

Procedure for Boiler Derating

Consistent with USEPA derating determinations, to derate a boiler the change must:

1. Be accomplished through a permanent physical change to the affected facility which will preclude it from operating at a capacity greater than the derated value;
2. Be a change that cannot be easily undone;
3. Require a system shutdown to make the change or to reverse it; and
4. Reduce the capacity, not the feed rate, of the boiler.

